

TITAN 3 Supported Cameras

Nikon Cameras

Using EN-EL14 battery - D3100, D3200, D3300, D3400, D3500, D5100, D5200, D5300, D5500, D5600

Using EN-EL15 battery - D500, D600, D610, D750, D800, D800E, D810, D850, D7000, D7100, D7200, D7500

Canon Cameras

Using LP-E17 battery - Canon 77D, 200D, 1100D, 1200D, 1300D, 550D, 600D, 700D, 760D, 800D, Rebel T6, T7

Using LP-E6 battery - Canon 5D Mark III, 6D Mark I, II, 7D, 7D Mark II, 60D, 70D, 80D, EOS R

*** Sony Cameras**

Using NP-FW50 battery - NEX 5, Sony A7, A7II, A7R, A7S, A7RII, A7S, A5000, A5100, A6000, A6300, A6500

The TITAN3 Remote Solar & AC does not support Sony Cameras